Gio Pelle Mobile Magnification Light Assemble & Operating Instructions



Step 1 Insert pole into 5 star caster base.



Step 2

Turn pole and base upside down. Place weight onto bottom of the base. It is recommended that a second person hold the base and pole while the weight is being attached.



Step 3 Insert bolt into weight bottom and into pole.



Step 4 Tighten bolt.





Step 5

Turn lamp right side up. Insert lamp into top of pole.



Step 6 Tighten knob to secure lamp to pole.

Operating Instructions

- **1.** Plug lamp into a standard three prong wall outlet.
- 2. Adjust lamp arm and head for personal preferance. Lamp arm extends up to 33" and can be positioned at 90° without tipping with weight attached to bottom.
- **3.** Press the **ON** button located on the lamp head.